


# AT5600 Screen Protector Fitting Instructions

The AT5600 Transformer Tester has a glass covered industrial spec touch screen display. This kit contains everything you need to fit a plastic screen protector to the unit to protect the screen and prevent scratches. The kit contains a screen protector with black protective backing, a micro fibre cloth for cleaning and an applicator tool. The following instructions explain how to fit or replace the screen protector. Please contact us for free replacements.


## 1 CLEAN SCREEN

First, clean the screen using the supplied microfiber cleaning cloth. You may wish to use a small amount of anti-static cleaner on the display to help remove any grease and fingerprints.



## 2 PEEL BACK PROTECTOR BACKING

Take the screen protector and carefully peel back 1/4 of the black protective cover from the shortest side. Be careful to NOT touch the exposed back of the screen protector.



## 3 FIT PROTECTOR

Apply the screen protector to the display. Peel the back in steps from left to right as you use the applicator tool to remove any air bubbles as you apply each section.



## 4 REMOVE AIR BUBBLES

Once all the backing is removed you can then use the film applicator tool to push any remaining air bubbles to the sides of the screen. The cloth can be used to keep the screen clean.

